STAMP-IT

VUESTAMP SIZE CHART

For use with an ink pad

Sizes in millimeters. Measured from lower left corner of mount